Obsolete 2098 Drives include:

Model Name	Model Description
2098-IPD-075-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-150-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV030 -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV030-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV050 -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV050-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV100 -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV100-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV150 -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV150-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV220 -	ULTRA 5000 SERVO DRIVE
2098-IPD-HV220-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-005 -	ULTRA 5000 SERVO DRIVE
2098-IPD-005-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-010 -	ULTRA 5000 SERVO DRIVE
2098-IPD-010-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-020 -	ULTRA 5000 SERVO DRIVE
2098-IPD-020-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-030 -	DRIVE 15A/30A ULT MC
2098-IPD-030-DN -	ULTRA 5000 SERVO DRIVE
2098-IPD-075 -	ULTRA 5000 SERVO DRIVE
2098-IPD-150 -	ULTRA 5000 SERVO DRIVE